

Table of Contents

1.0	Getting Familiar with the Editor	1-1
1.1	Overview of the AutoMax Ladder Editor Window	1-1
1.2	Opening Programs	1-2
1.3	Closing Programs	1-3
1.4	Saving Programs	1-3
1.5	Saving Programs Automatically As You Work	1-4
1.6	Displaying a Program in Multiple Windows	1-4
1.7	Editing Different Parts of the Same Program Using Split Windows	1-5
1.8	Editing Multiple Programs	1-5
1.9	Displaying/Hiding Revision Marks While Editing Programs Offline	1-6
1.10	About Program Properties	1-7
1.11	About Program Execution	1-7
1.11.1	Specifying a Scan Time to Control Program Execution	1-8
1.11.2	Specifying a Hardware Event to Control Program Execution	1-8
1.11.3	Specifying a Software Event to Control Program Execution	1-9
1.12	Running and Stopping Ladder Programs	1-10
1.13	Exiting the Ladder Editor	1-10
2.0	Editing Programs	2-1
2.1	Starting a Rung	2-1
2.1.1	Defining the Horizontal and Vertical Grid Limits Per Rung	2-2
2.1.2	Turning the Grid On and Off	2-2
2.2	Selecting Rungs	2-2
2.3	Entering Rung Descriptions	2-4
2.4	Inserting Instructions into a Rung	2-5
2.5	Connecting Instructions (Drawing Wires)	2-6
2.6	Connecting Multiple Instructions by Using the ENO Output Bit	2-6
2.7	Selecting Instructions	2-7
2.8	About Instruction Properties	2-8
2.9	Changing an Instruction Type	2-9
2.10	Assigning Variables and Constants to Ladder Instruction Parameters	2-10
2.11	Entering Variable Descriptions	2-11
2.12	Using Variable Smart-Matching	2-12
2.13	Selecting Variable Names	2-13
2.14	Changing a Variable's Data Type	2-13
2.15	Changing a Variable's Scope	2-14
3.0	Printing Programs	3-1
3.1	What Is Included in a Printed Copy of a Program	3-2
3.2	Setting Print Options	3-4
3.3	Defining the Page Setup	3-5
3.4	How a Rung Is Printed To Fit on a Single Page	3-6

3.5	Inserting and Deleting Page Breaks	3-7
3.6	Printing a Range of Rungs	3-7
3.7	Displaying and Printing Coils as Right-Justified	3-8
3.8	Printing Multiple Copies of Programs	3-8
4.0	Verifying Programs	4-1
4.1	Creating a Verify Error Log File	4-2
4.2	Automatically Checking the Variable Configurator Database While Verifying a Program	4-2
4.3	Specifying Whether To Include Warning Messages When Verifying Programs	4-3
4.4	Resolving Verify Errors	4-3
5.0	Editing Programs Online	5-1
5.1	About the States of Online Programs	5-2
5.2	Monitoring an Online Ladder Program	5-4
5.3	Pausing the Editor	5-5
5.4	About Power Flow	5-5
5.5	Monitoring Data in an Online Program	5-6
5.6	Accepting Changes Made to Online Programs	5-6
5.7	Downloading Changes Made to an Online Program (Commit Online Changes)	5-7
5.8	Testing Programs (Test Mode)	5-9
5.8.1	Committing an Online Program in Test Mode (Commit Changes in Test Mode)	5-9
5.8.2	Removing an Online Program from Test Mode	5-10
5.8.3	Canceling All Changes Made to an Online Program	5-10
5.9	About How Changes Made to Online Programs Are Verified	5-11
5.10	Viewing an Online Program as It Looked before It Was Edited	5-12
5.11	Capturing the State of Logic in an Online Program	5-13
5.11.1	Capturing the State of Logic Based on a Coil Becoming True	5-14
5.11.2	Capturing the State of Logic Based on a Coil Becoming False	5-14
5.11.3	Capturing the State of Logic Based on a Rung Error	5-15
5.11.4	Waiting for Triggers While Continuing To Edit	5-15
5.11.5	Re-Activating a Trigger	5-15
5.11.6	Clearing a Trigger	5-16
5.12	Setting and Forcing Variables in Ladder Programs	5-16
5.12.1	Setting Variables	5-18
5.12.2	Forcing Variables	5-19
5.12.3	Unforcing Variables	5-20
5.12.4	About the Expanded Set/Force/Unforce Dialog Box	5-21
5.12.5	Viewing the Total Number of Forced Variables	5-21
5.12.6	Viewing a List of Set or Forced Variables	5-21
5.12.7	Unforcing an Entire Force Page	5-21
5.12.8	Testing If Variables in the Rack Are Forced	5-22
5.13	Viewing and Clearing Run-Time Errors	5-22

Appendices

Appendix A	
Toolbars, Palettes, and the Status Bar	A-1
Appendix B	
Keyboard Shortcuts	B-1
Appendix C	
Using the Pre-Defined (Reserved) Ladder Language Variables	C-1
Appendix D	
Online Editing Memory Limits	D-1
Appendix E	
Rung Execution Order	E-1
Appendix F	
Converting Ladder Programs Created Using an Older Version of AutoMax	F-1
Appendix G	
Glossary	G-1