

1.0	Relay Instructions	1-1
1.1	Normally Open Contact (NOI)	1-2
1.2	Normally Closed Contact (NCI)	1-3
1.3	Positive Transition Contact (PTI)	1-4
1.4	Negative Transition Contact (NTI)	1-5
1.5	Using Transition Contacts	1-6
1.5.1	Using a Variable Only on a Transition Contact	1-6
1.5.2	Using a Variable on a Coil and on a Transition Contact	1-7
1.5.3	Using a Variable on More Than One Coil and On a Transition Contact	1-8
1.5.4	Forcing or Setting Variables Used on Transition Contacts	1-9
1.5.5	Using a Variable on a Set (SCO) Coil and Reset Coil (RCO) Pair and on a Transition Contact	1-10
1.5.6	Using Transition Contacts in a Program with a Jump and Label Construct	1-11
1.6	Always True Contact (ATI)	1-12
1.7	Always False Contact (AFI)	1-13
1.8	Coil (CO)	1-14
1.9	Set (Latch) Coil (SCO)	1-15
1.10	Reset (Unlatch) Coil (RCO)	1-16
1.11	Errors Caused by the Relay Instructions	1-17
2.0	Counter Instruction	2-1
2.1	Count Up Down (CTUD)	2-2
2.1.1	Input Parameters for the Count Up Down Instruction	2-3
2.1.2	Output Parameters for the Count Up Down Instruction	2-4
2.1.3	Example of a Count Up Down Instruction	2-5
2.2	Resetting a Counter	2-5

2.3	Changing the Preset Value of a Counter Instruction by Using Ladder Logic	2-6
3.0	Timer Instructions	3-1
3.1	Retentive Timer On (RTO)	3-3
3.1.1	Input Parameters for the RTO Instruction	3-4
3.1.2	Output Parameters for the RTO Instruction	3-5
3.1.3	RTO Timing Diagram	3-6
3.1.4	Example of an RTO Instruction	3-7
3.2	Timer Off Delay (TOF)	3-7
3.2.1	Input Parameters for the TOF Instruction	3-8
3.2.2	Output Parameters for the TOF Instruction	3-9
3.2.3	TOF Timing Diagram	3-10
3.2.4	Example of a TOF Instruction	3-11
3.3	Timer On Delay (TON)	3-11
3.3.1	Input Parameters for the TON Instruction	3-12
3.3.2	Output Parameters for the TON Instruction	3-13
3.3.3	TON Timing Diagram	3-14
3.3.4	Example of a TON Instruction	3-15
3.4	Timer Pulse (TP)	3-15
3.4.1	Input Parameters for the TP Instruction	3-16
3.4.2	Output Parameters for the TP Instruction	3-17
3.4.3	TP Timing Diagram	3-18
3.4.4	Example of a TP Instruction	3-19
3.5	Changing the Preset Value of a Timer Instruction by Using Ladder Logic	3-19

4.0	Compare Instructions	4-1
4.1	Equal To (EQ)	4-2
4.1.1	Input Parameters for the Equal To Instruction	4-3
4.1.2	Output Parameters for the Equal To Instruction	4-4
4.1.3	Example of an Equal To Instruction	4-5
4.2	Greater Than Or Equal To (GE)	4-6
4.2.1	Input Parameters for the Greater Than Or Equal To Instruction	4-7
4.2.2	Output Parameters for the Greater Than Or Equal To Instruction	4-8
4.2.3	Example of a Greater Than Or Equal To Instruction	4-9
4.3	Greater Than (GT)	4-10
4.3.1	Input Parameters for the Greater Than Instruction	4-11
4.3.2	Output Parameters for the Greater Than Instruction	4-12
4.3.3	Example of a Greater Than Instruction	4-13
4.4	Less Than Or Equal To (LE)	4-14
4.4.1	Input Parameters for the Less Than Or Equal To Instruction	4-15
4.4.2	Output Parameters for the Less Than Or Equal To Instruction	4-16
4.4.3	Example of a Less Than Or Equal To Instruction	4-17
4.5	Less Than (LT)	4-18
4.5.1	Input Parameters for the Less Than Instruction	4-19
4.5.2	Output Parameters for the Less Than Instruction	4-20
4.5.3	Example of a Less Than Instruction	4-21

4.6	Limit (LIMIT)	4-22
4.6.1	Input Parameters for the Limit Instruction	4-23
4.6.2	Output Parameters for the Limit Instruction	4-24
4.6.3	Example of a Limit Instruction	4-25
4.7	Mask Compare (MSK)	4-26
4.7.1	Input Parameters for the Mask Compare Instruction	4-27
4.7.2	Output Parameters for the Mask Compare Instruction	4-28
4.7.3	Example of a Mask Compare Instruction	4-29
4.8	Not Equal To (NE)	4-30
4.8.1	Input Parameters for the Not Equal To Instruction	4-31
4.8.2	Output Parameters for the Not Equal To Instruction	4-32
4.8.3	Example of a Not Equal To Instruction	4-33
4.9	Errors Caused by Compare Instructions	4-33
4.9.1	Errors Caused by All Compare Instructions	4-34
4.9.2	Errors Caused by the Limit Instruction	4-34
5.0	Compute Instructions	5-1
5.1	Absolute Value (ABS)	5-2
5.1.1	Input Parameters for the Absolute Value Instruction	5-3
5.1.2	Output Parameters for the Absolute Value Instruction	5-4
5.1.3	Example of an Absolute Value Instruction	5-4
5.2	Add (ADD)	5-5
5.2.1	Input Parameters for the Add Instruction	5-6
5.2.2	Output Parameters for the Add Instruction	5-7
5.2.3	Example of the Add Instruction	5-8

5.3	Divide (DIV)	5-9
5.3.1	Input Parameters for the Divide Instruction	5-10
5.3.2	Output Parameters for the Divide Instruction	5-11
5.3.3	Example of a Divide Instruction	5-12
5.4	Modulo (MOD)	5-12
5.4.1	Input Parameters for the Modulo Instruction	5-13
5.4.2	Output Parameters for the Modulo Instruction	5-14
5.4.3	Example of the Modulo Instruction	5-15
5.5	Multiply (MUL)	5-15
5.5.1	Input Parameters for the Multiply Instruction	5-16
5.5.2	Output Parameters for the Multiply Instruction	5-17
5.5.3	Example of a Multiply Instruction	5-18
5.6	Multiply Divide (MDV)	5-19
5.6.1	Input Parameters for the Multiply Divide Instruction	5-20
5.6.2	Output Parameters for the Multiply Divide Instruction	5-21
5.6.3	Example of a Multiply Divide Instruction	5-22
5.7	Negate (NEG)	5-22
5.7.1	Input Parameters for the Negate Instruction	5-23
5.7.2	Output Parameters for the Negate Instruction	5-24
5.7.3	Example of a Negate Instruction	5-24
5.8	Square Root (SQRT)	5-25
5.8.1	Input Parameters for the Square Root Instruction	5-26
5.8.2	Output Parameters for the Square Root Instruction	5-27
5.8.3	Example of the Square Root Instruction	5-28
5.9	Subtract (SUB)	5-28
5.9.1	Input Parameters for the Subtract Instruction	5-29
5.9.2	Output Parameters for the Subtract Instruction	5-30
5.9.3	Example of a Subtract Instruction	5-31

5.10	Errors Caused by the Compute Instructions	5-31
5.10.1	Errors Caused by All Compute Instructions	5-32
5.10.2	Errors Caused by the Absolute Value Instruction	5-33
5.10.3	Errors Caused by the Addition Instruction	5-33
5.10.4	Errors Caused by the Divide, Modulo, and Multiply Divide Instruction	5-34
5.10.5	Errors Caused by the Multiply Instruction	5-35
5.10.6	Errors Caused by the Negate Instruction	5-36
5.10.7	Errors Caused by the Square Root Instruction	5-37
5.10.8	Errors Caused by the Subtract Instruction	5-38
6.0	Logical Instructions	6-1
6.1	Logical And (AND)	6-2
6.1.1	Input Parameters for the Logical AND Instruction	6-3
6.1.2	Output Parameters for the Logical AND Instruction	6-3
6.1.3	Example of a Logical AND Instruction	6-4
6.2	Logical Not (NOT)	6-5
6.2.1	Input Parameters for the Logical NOT Instruction	6-6
6.2.2	Output Parameters for the Logical NOT Instruction	6-6
6.2.3	Example of a Logical NOT Instruction	6-7
6.3	Logical Or (OR)	6-8
6.3.1	Input Parameters for the Logical OR Instruction	6-9
6.3.2	Output Parameters for the Logical OR Instruction	6-9
6.3.3	Example of a Logical OR Instruction	6-10

6.4	Logical Exclusive Or (XOR)	6-11
6.4.1	Input Parameters for the Logical Exclusive OR Instruction	6-12
6.4.2	Output Parameters for the Logical Exclusive OR Instruction	6-12
6.4.3	Example of a Logical Exclusive OR Instruction	6-13
6.5	Errors Caused by Logical Instructions	6-14
7.0	Data Conversion Instructions	7-1
7.1	Convert Integer Data to BCD (TO_BCD)	7-2
7.1.1	Input Parameters for the Convert Integer Data to BCD Instruction	7-3
7.1.2	Output Parameters for the Convert Integer Data to BCD Instruction	7-4
7.1.3	Example of a Convert Integer Data To BCD Instruction	7-5
7.2	Convert From BCD to Integer Data (BCD_TO)	7-6
7.2.1	Input Parameters for the Convert From BCD to Integer Data Instruction	7-7
7.2.2	Output Parameters for the Convert From BCD to Integer Data Instruction	7-8
7.2.3	Example of a Convert From Binary Data to Integer Data Instruction	7-9
7.3	Errors Caused by the Data Conversion Instructions	7-10
7.3.1	Errors Caused by All Data Conversion Instructions	7-10
7.3.2	Errors Caused by the Convert Integer Data To BCD Instruction	7-11
7.3.3	Errors Caused by the Convert From Binary Data to Integer Data Instruction	7-12

8.0	Move Instructions	8-1
8.1	Move Source Data to Destination (MOVE)	8-2
8.1.1	Input Parameters for the Move Source Data to Destination Instruction	8-3
8.1.2	Output Parameters for the Move Source Data to Destination Instruction	8-4
8.1.3	Example of a Move Source Data to Destination Instruction	8-5
8.2	Move Bits Between Integers/Double Integers (MVB)	8-6
8.2.1	Input Parameters for the Move Bits Between Integers/ Double Integers Instruction	8-7
8.2.2	Output Parameters for the Move Bits Between Integers/ Double Integers Instruction	8-8
8.2.3	Examples of a Move Bits Between Integers/ Double Integers Instruction	8-9
8.3	Masked Move (MVM)	8-10
8.3.1	Input Parameters for the Masked Move Instruction	8-11
8.3.2	Output Parameters for the Masked Move Instruction	8-12
8.3.3	Example of a Masked Move Instruction	8-13
8.4	Errors Caused by Move Instructions	8-14
8.4.1	Errors Caused by All Move Instructions	8-14
8.4.2	Errors Caused by the Move Source Data to Destination Instruction	8-15
8.4.3	Errors Caused by the Move Bits between Integers/Double Integers Instruction	8-16

9.0	Shift Register Instructions	9-1
9.1	Shift Left (SL)	9-3
9.1.1	Input Parameters for the Shift Left Instruction	9-4
9.1.2	Output Parameters for the Shift Left Instruction	9-5
9.1.3	Example of a Shift Left Instruction	9-6
9.2	Circular Rotate Bits Left (ROL)	9-7
9.2.1	Input Parameters for the Circular Rotate Bits Left Instruction	9-8
9.2.2	Output Parameters for the Circular Rotate Bits Left Instruction	9-9
9.2.3	Example of a Circular Rotate Bits Left Instruction	9-10
9.3	Circular Rotate Bits Left on Transition (RL)	9-11
9.3.1	Input Parameters for the Circular Rotate Bits Left on Transition Instruction	9-12
9.3.2	Output Parameters for the Circular Rotate Bits Left On Transition Instruction	9-13
9.3.3	Example of a Circular Rotate Bits Left On Transition Instruction	9-14
9.4	Shift Right (SR)	9-15
9.4.1	Input Parameters for the Shift Right Instruction	9-16
9.4.2	Output Parameters for the Shift Right Instruction	9-17
9.4.3	Example of a Shift Right Instruction	9-18
9.5	Circular Rotate Bits Right (ROR)	9-19
9.5.1	Input Parameters for the Circular Rotate Bits Right Instruction	9-20
9.5.2	Output Parameters for the Circular Rotate Bits Right Instruction	9-21
9.5.3	Example of a Circular Rotate Bits Right Instruction	9-22

9.6	Circular Rotate Bits Right on Transition (RR)	9-23
9.6.1	Input Parameters for the Circular Rotate Bits Right on Transition Instruction	9-24
9.6.2	Output Parameters for the Circular Rotate Bits Right On Transition Instruction	9-25
9.6.3	Example of a Circular Rotate Bits Right On Transition Instruction	9-26
9.7	Errors Caused by Shift Register Instructions	9-27
9.7.1	Errors Caused by All Shift Register Instructions	9-27
9.7.2	Errors Caused by the Circular Rotate Bits Left, Circular Rotate Bits Left on Transition, Circular Rotate Bits Right, and Circular Rotate Bits Right on Transition Instructions .	9-28
10.0	Array Instructions	10-1
10.1	Unary Array Instruction (AR1)	10-5
10.1.1	Input Parameters for the Unary Array Instruction	10-6
10.1.2	Output Parameters for the Unary Array Instruction	10-9
10.1.3	Example of an Unary Array Instruction	10-11
10.2	Multi-Array Instruction (AR2)	10-12
10.2.1	Input Parameters for the Multi-Array Instruction	10-14
10.2.2	Output Parameters for the Multi-Array Instruction	10-18
10.2.3	Example of a Multi-Array Instruction	10-19
10.3	Array Compare (ARC)	10-20
10.3.1	Input Parameters for the Array Compare Instruction	10-22
10.3.2	Output Parameters for the Array Compare Instruction	10-26
10.3.3	Example of an Array Compare Instruction	10-27

10.4	Array Shift Up (ASU)	10-28
10.4.1	Input Parameters for the Array Shift Up Instruction	10-29
10.4.2	Output Parameters for the Array Shift Up Instruction	10-30
10.4.3	Example of an Array Shift Up Instruction	10-31
10.5	Array Shift Down (ASD)	10-32
10.5.1	Input Parameters for the Array Shift Down Instruction	10-33
10.5.2	Output Parameters for the Array Shift Down Instruction	10-34
10.5.3	Example of an Array Shift Down Instruction	10-35
10.6	About the State of the Unary Array, Multi-Array, and Array Compare Instruction Outputs under Various Input Conditions	10-36
10.7	Errors Caused by Array Instructions	10-37
10.7.1	Errors Caused by the Unary Array Instruction	10-37
10.7.2	Errors Caused by the Multi-Array Instruction	10-39
10.7.3	Errors Caused by the Array Compare Instruction	10-41
10.7.4	Errors Caused by the Array Shift Up and Array Shift Down Instructions	10-42
11.0	Program Control Instructions	11-1
11.1	Set Event (SET)	11-2
11.1.1	Input Parameters for the Set Event Instruction	11-3
11.1.2	Output Parameters for the Set Event Instruction	11-3
11.1.3	Example of the SET Instruction	11-4
11.2	Jump (JMP)	11-5
11.3	Label (LBL)	11-5
11.4	Example of Using the Jump and Label Instruction	11-6
11.5	The Error Caused by the Jump Instruction	11-7

12.0 I/O Read and Write Instructions	12-1
12.1 I/O Read (IOR)	12-2
12.1.1 Input Parameters for the I/O Read Instruction	12-3
12.1.2 Output Parameters for the I/O Read Instruction	12-5
12.1.3 Defining the Amount of I/O Data to Read	12-6
12.1.4 Example of an I/O Read Instruction	12-7
12.2 I/O Write (IOW)	12-8
12.2.1 Input Parameters for the I/O Write Instruction	12-9
12.2.2 Output Parameters for the I/O Write Instruction	12-10
12.2.3 Defining the Amount of I/O Data to Write	12-11
12.2.4 Example of an I/O Write Instruction	12-12
12.3 Listing of Base Addresses for Each Supported Slot in the AutoMax Chassis	12-13
12.4 Errors Caused by the I/O Read and I/O Write Instructions	12-14
13.0 Immediate Input and Output Instructions	13-1
13.1 Immediate Input (IN)	13-2
13.1.1 Input Parameters for the Immediate Input Instruction	13-3
13.1.2 Output Parameters for the Immediate Input Instruction	13-4
13.1.3 Example of an Immediate Input Instruction	13-4
13.2 Immediate Output (OUT)	13-5
13.2.1 Input Parameters for the Immediate Output Instruction	13-5
13.2.2 Output Parameters for the Immediate Output Instruction	13-6
13.2.3 Example of an Immediate Output Instruction	13-6

Appendix A

Using Variables	A-1
A.1 Data Types	A-3
A.1.1 Boolean Variables	A-3
A.1.2 Integer and Double Integer Variables	A-4
A.1.3 Timer Variables	A-6
A.1.4 Counter Variables	A-8
A.1.5 Labels	A-9
A.2 Accessing Data Within Variables Via Bit-Indexing and Element-Indexing	A-10
A.3 Global and Local Variables (Scope)	A-11
A.3.1 Local Variables	A-11
A.3.2 Global Variables	A-12
A.4 Arrays	A-13
A.5 Constants	A-15
A.6 About Initializing Variables	A-15
A.6.1 About the No Initialization (No Init.) Method	A-16
A.6.2 About the User Specified Initialization Method	A-18
A.6.3 About the Retained Value Initialization Method	A-18
A.6.4 About Initializing Timer and Counter Variables	A-19
A.6.5 About Initializing Arrays	A-19
A.6.6 Defining the Type of Initialization To Use for a Variable ..	A-20
A.6.7 Defining the Initial Value of a Variable	A-21

Appendix B

Using Timer Variables in BASIC Programs	B-1
---	-----

Appendix C

Using Counter Variables in BASIC Programs	C-1
---	-----

Appendix D

Using the Pre-Defined (Reserved) Ladder Language Variables	D-1
D.1 Using the Pre-Defined Program Scan Variables	D-2
D.2 Using the Pre-Defined Error Handling Variables	D-3
D.3 Using the Pre-Defined Ladder Execution Time Variables	D-4

Appendix E

Ladder Instruction Error Code Cross-Reference	E-1
E.1 Error Codes 3001-3010	E-2
E.2 Error Codes 3011-3020	E-3
E.3 Error Codes 3021-3030	E-4
E.4 Error Codes 3031-3035	E-5

Appendix F

AutoMax Enhanced Ladder Language Execution Times and Memory Usage for AutoMax 7010 & 6011	F-1
--	-----

Appendix G

AutoMax Enhanced Ladder Language Execution Times and Memory Usage for AutoMax PC3000	G-1
---	-----

Appendix H

Glossary	H-1
--------------------	-----