


Appendix M

Part Numbers of UDC Operating System Versions

422544-034B-00	SD3000 + SF3000	V3.4C	UDC OS included w/ Executive software
422544-134C-00	SA3000 + SA500	V3.4C	
422544-234C-00	SD3000 + SA3000	V3.4C	
422544-334B-00	SD3000 + SA500	V3.4C	
422544-034D-00	SD3000 + SF3000	V3.4D	
422544-134D-00	SA3000 + SA500	V3.4D	
422544-234D-00	SD3000 + SA3000	V3.4D	
422544-334D-00	SD3000 + SA500	V3.4D	
422544-034E-00	SD3000 + SF3000	V3.4E	
422544-134D-00	SA3000 + SA500	V3.4E	
422544-234E-00	SD3000 + SA3000	V3.4E	
422544-334E-00	SD3000 + SA500	V3.4E	

Beginning with AutoMax Executive Version 3.5, the UDC operating systems are not included with the Executive software. Instead, they are included in the separate DPS options software. The example that follows shows how to determine the UDC and PMI operating system numbers that are displayed on the Info/Log UDC Information screen.

N N A N - N N N N - N N N N



PMI OS Types

- 0=SD3000
- 1=SF3000
- 2=SA3000 Vector
- 3=SA500 Brushless DC
- 4=VZ3000
- 5=SB3000
- 6=Medium Voltage
- 7=SA3000 Constant Power
- 8=SA500 Speed Loop
- 9=SA3000 V/Hz
- A=SA3100 Constant Power
- B=SA3100 V/Hz