

**AutoMax[®]
Control Block
Language**

Instruction Manual J-3676-5

 **Rockwell** Automation

Reliance Electric

The information in this user's manual is subject to change without notice.

WARNING

PROGRAMS INSERTED INTO THE PRODUCT SHOULD BE REVIEWED BY QUALIFIED PERSONNEL WHO ARE FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE SYSTEM AND THE POTENTIAL HAZARDS INVOLVED. FAILURE TO OBSERVE THIS PRECAUTION COULD RESULT IN BODILY INJURY OR DAMAGE TO EQUIPMENT.

WARNING

ALL USERS MUST PROVIDE A HARDWIRED EMERGENCY STOP CIRCUIT OUTSIDE THE PROGRAMMABLE CONTROLLER CIRCUITRY. FAILURE TO OBSERVE THIS PRECAUTION COULD RESULT IN BODILY INJURY OR DAMAGE TO EQUIPMENT.

WARNING

ONLY QUALIFIED PERSONNEL MAY INSTALL, ADJUST, OPERATE, AND MAINTAIN THIS EQUIPMENT. READ AND UNDERSTAND THIS INSTRUCTION MANUAL BEFORE ANY WORK IS PERFORMED. FAILURE TO OBSERVE THIS PRECAUTION COULD RESULT IN BODILY INJURY OR DAMAGE TO EQUIPMENT.

WARNING

ONLY QUALIFIED PERSONNEL WHO HAVE READ AND UNDERSTOOD ALL APPLICABLE AUTOMAX INSTRUCTION MANUALS AND ARE THOROUGHLY FAMILIAR WITH THE PARTICULAR APPLICATION MAY UTILIZE THE ON-LINE PROGRAMMING OPTION PROVIDED IN THE AUTOMAX PROGRAMMING SOFTWARE. FAILURE TO OBSERVE THIS PRECAUTION COULD RESULT IN BODILY INJURY OR DAMAGE TO EQUIPMENT.

Norton® is a registered trademark of Peter Norton Computing, Inc.

IBM-XT™ and AT™ are trademarks of IBM.

Toshiba™ is a trademark of Toshiba America.

Microsoft™, Windows™, and MS-DOS™ are trademarks of Microsoft.

Reliance®, AutoMax®, and AutoMate® are registered trademarks of Reliance Electric Company or its subsidiaries.

ReSource™, Shark™ and R-NET™ are trademarks of Reliance Electric Company or its subsidiaries.