

Table of Contents

1.0	Overview	1-1
1.1	Introduction	1-1
1.2	This Manual	1-1
1.3	Related Publications	1-1
2.0	I/O Rail	2-1
2.1	Introduction	2-1
2.2	General Description	2-1
2.2.1	Rail Chassis	2-1
2.2.2	Rail Terminal Strip	2-3
2.2.3	Rail Motherboard	2-6
2.3	Rail Installation and Mounting	2-7
2.3.1	Grounding	2-11
2.3.2	Rail Cabling Channel Kit	2-12
2.3.3	Horizontal I/O Cable Channel Kit	2-12
2.3.4	Rail Jumper Bar Kit	2-15
2.4	I/O Wiring	2-16
3.0	Digital I/O Modules	3-1
3.1	Introduction	3-1
3.2	Dual A-C/D-C Input Module	3-1
3.3	Dual Electronic Input Module	3-5
3.4	Voltage Comparator Module	3-10
3.5	Dual A-C Output Module	3-14
3.6	Dual D-C Output Module	3-18
3.7	Dual Contact Output Module - Normally Open Contacts	3-22
3.8	Dual Contact Output Module - Normally Closed Contacts	3-26
3.9	Dual Dry Contact Output Module	3-30
4.0	Diagnostics and Troubleshooting	4-1
4.1	Introduction	4-1
4.2	Locating an I/O Rail Fault	4-1
4.2.1	AutoMate 15	4-1
4.2.2	AutoMate 20/20E	4-6
4.2.3	AutoMate 30/30E	4-14
4.2.4	AutoMate 40/40E	4-26
4.2.5	DCS 5000/AutoMax	4-34
4.3	Testing an AutoMate Input Circuit	4-41
4.4	Testing an AutoMate Output Circuit	4-42
4.5	Testing a DCS 5000/AutoMax Rail-Mounted Input Circuit	4-44
4.6	Testing a DCS 5000/AutoMax Rail-Mounted Output Circuit	4-46

Appendices

Appendix A

I/O Rail Mounting Dimensions	A-1
------------------------------------	-----

List of Figures

Figure 2.1	- I/O Rail (Front View)	2-2
Figure 2.2	- I/O Rail (Top View)	2-3
Figure 2.3	- Rail Terminal Strip	2-4
Figure 2.4	- Terminal Strip Assembly	2-5
Figure 2.5	- Rail Motherboard	2-6
Figure 2.6	- Rail Mounting Dimensions	2-8
Figure 2.7	- Rail Mounting Examples	2-9
Figure 2.8	- Typical Rail Installations	2-10
Figure 2.9	- Grounding	2-11
Figure 2.10	- Rail Cabling Channel	2-12
Figure 2.11	- Horizontal Channel Dimensions	2-13
Figure 2.12	- Typical Horizontal Channel Applications	2-14
Figure 2.13	- Jumper Bar	2-15
Figure 2.14	- Jumper Bar Installation	2-15
Figure 2.15	- Field Wiring Example	2-17
Figure 3.1	- Dual A-C/D-C Input Module	3-2
Figure 3.2	- Dual A-C/D-C Input Module Channel Schematic	3-2
Figure 3.3	- Dual A-C/D-C Input Module Field Wiring Example	3-3
Figure 3.4	- Dual Electronic Input Module	3-6
Figure 3.5	- Schematic of a Dual Electronic Input Module	3-7
Figure 3.6	- Dual Electronic Input Module Field Wiring Example	3-7
Figure 3.7	- Dual Electronic Input Module Timing Diagram	3-8
Figure 3.8	- Voltage Comparator Module	3-11
Figure 3.9	- Voltage Comparator Schematic	3-11
Figure 3.10	- Voltage Comparator Module Field Wiring Example	3-12
Figure 3.11	- Deadband Adjustment	3-12
Figure 3.12	- Dual A-C Output Module	3-15
Figure 3.13	- A-C Output Channel Schematic	3-15
Figure 3.14 (A)	- Dual A-C Output Module Field Wiring Example	3-16
Figure 3.14 (B)	- RC Suppression Network for Inductive Loads	3-16
Figure 3.15	- Dual D-C Output Module	3-19
Figure 3.16	- Dual D-C Output Module Channel Schematic	3-20
Figure 3.17	- Dual D-C Output Module Field Wiring Example	3-20
Figure 3.18	- Dual Contact Output Module (N.O.)	3-23
Figure 3.19	- Schematic of a Dual Contact Output Module (N.O.) Channel	3-23
Figure 3.20	- Dual Contact Output Module (N.O.) Field Wiring Example	3-24
Figure 3.21	- Dual Contact Output Module (N.C.)	3-27
Figure 3.22	- Schematic of a Dual Contact Output Module (N.C.) Channel	3-27
Figure 3.23	- Dual Contact Output Module (N.C.) Field Wiring Example	3-28
Figure 3.24	- Dual Dry Contact Output Module	3-30
Figure 3.25	- Schematic of a Low Power Output Channel	3-31
Figure 3.26	- Low Power Circuit Example	3-31
Figure 3.27	- Dual Dry Contact Output Module Field Wiring Example	3-32
Figure 4.1	- AutoMate 15 Rail Fault Troubleshooting Flowchart	4-2
Figure 4.2	- Motherboard Retaining Screws	4-5
Figure 4.3	- AutoMate 20/20E Rail Fault Troubleshooting Flowchart	4-6
Figure 4.4	- AutoMate 30/30E and 40/40E Rail Fault Troubleshooting Flowchart	4-15
Figure 4.5	- DCS 5000/AutoMax Rail Fault Troubleshooting Flowchart	4-35

List of Tables

Table 3.1	- Dual A-C/D-C Input Module Technical Specifications	3-4
Table 3.2	- Dual Electronic Input Module Technical Specifications	3-9
Table 3.3	- Dual Electronic Input Module Current and Voltage Specifications	3-9
Table 3.4	- Voltage Comparator Module Technical Specifications	3-13
Table 3.5	- Dual A-C Output Module Technical Specifications	3-17
Table 3.6	- Dual A-C Output Module Electrical Specifications	3-17
Table 3.7	- Dual D-C Output Module Technical Specifications	3-21
Table 3.8	- Dual Contact Output Module (N.O.) Technical Specifications	3-25
Table 3.9	- Dual Contact Output Module (N.C.) Technical Specifications	3-29
Table 3.10	- Dual Dry Contact Output Module Technical Specifications	3-33
Table 4.1	- AutoMate 15 Rail Fault LED Error Codes	4-3
Table 4.2	- AutoMate 20/20E Rail Fault LED Error Codes	4-10
Table 4.3	- AutoMate 20/20E Rail Fault Register 2750	4-11
Table 4.4	- AutoMate 30/30E Rail Fault Registers 3750/3751	4-21
Table 4.5	- Remote I/O Head Rail Fault LED Error Codes	4-24
Table 4.6	- AutoMate 40 Rail Fault Registers 17600-17607	4-28
Table 4.7	- AutoMate 40E Rail Fault Registers 17600-17637	4-29
Table 4.8	- DCS 5000/AutoMax Rail Fault LED Error Codes	4-38